

EP 30/44/50/60 Econocraft Options Instructions

Installing the optional Bottom Supply roll:

Install lower mandrel brackets as shown below with the included $\frac{1}{4}$ -20 button head screws.

If you have an existing unit in the field you will need to remove the bottom support rod (it may be blue or white depending upon the vintage of the machine) and install the enclosed idler tube. Use the included plated rod as the idler tube shaft. Discard the old shaft. You will need to remove both side covers to access the screws for the rod. Slide the shaft through the idler and reattach to the machine:



SUPPLY ROLL KIT: 2ND COMPLETE SUPPLY ROLL WITH STOP COLLAR, REPLACE LOWER STABILIZER WITH IDLER TUBE COMPLETE, & (2) FRONT SUPPLY ROLL BRACKETS. SECURE BOTH WITH $\frac{1}{4}$ -20 X $\frac{3}{4}$ BSH.

EP 30/44/50/60 Econocraft Options Instructions

Installing the optional Bottom Supply roll:

Install lower mandrel brackets as shown below.

If you have an existing unit in the field you will need to remove the bottom blue support rod and install the enclosed idler tube. Use the included plated rod as the idler tube shaft. Discard the blue shaft. You will need to remove both side covers to access the screws for the rod. Slide the shaft through the idler and reattach to the machine:



