

### **Replacing a Thermostat in a LEDCO Premier 3**

Remove the knob, then remove both plastic covers.

Disconnect the 2 heater wires (Label where they go).

Disconnect the 2 wires from the thermostat.(again, label where they go)

Remove the 4 screws that hold the top heat shoe on, be careful not to lose the spacers.

Remove the heat shoe, The thermostat is in the top hole in the heat shoe.

There will be a peened spot in the aluminum of the heat shoe that holds then thermostat in.

Take a utility knife and trim away the peened spot of the aluminum until the thermostat slides out.

Install the new one and peen it over just enough to hold it in.

Clean the rolls while the heat shoe is off, always a good idea as you'll have good access.

Reinstall the heat shoe, reconnect the wires and reinstall the side covers and the knob.

You're all set.