



**SCREWS AND FEEDTABLE SPACERS AS
ON THE RIGHT SIDE.**

- 7) ADD POTENTIOMETER WITH SOLDERED
WIRES TO RIGHT HOUSING BY PLACING
PAPER WASHER INSIDE HOUSING AND
THE TOOTHED WASHER AND NUT
OUTSIDE HOUSING. THE TERMINAL
POSTS SHOULD BE FACING UP AFTER
POTENTIOMETER IS TIGHTENED. ADD A
MINARIK KNOB (PRM221A) TO THE
OUTSIDE. GRAY WIRE GOES TO MOTOR
BOARD S1, YELLOW TO S2 AND ORANGE
TO S3.**

