

SM-330 LAMINATOR PART MANUAL

DRAWING NO	PART NO	DESCRIPTION	DRAWING NO	PART NO	DESCRIPTION
001	S3-A1	TOP COVER	019	3LM-D26	SPRING PAD
002	S3-A2	BASE	020	S3-D22	FOOT PAD
003	S3-D3	RACKET (LOWER-R)	021	R1366HA	REVERSE S.W
003-1	S3-D5	RACKET (UPPER-R)	022	S3-D24A	SET PIN
004	S3-D4	RACKET (LOWER-L)	025	S3-P5	AL PLATE
004-1	S3-D6	RACKET (UPPER-L)	026	S3-D25	SENSOR WIRE
005	S3-D1-1	UPPER-ROLLER (FRONT)	027	SF-129R1	CUT-OFF FUSE
005-1	S3-D1-2	LOWER-ROLLER (FRONT)	HS	S3-DH	HEATER SET
006	S3-D1-3	UPPER-ROLLER (REAR)	*	S3-D13	QUARTZ TUBE
006-1	S3-D1-4	LOWER-ROLLER (REAR)	*	S3-D13-1	QUARTZ TUBE CAP
007	S3-D7	HEAT-PLATE	*	3H1-P8-1	FIXED SCREW
008	S3-D8	GEAR	*	3H1-P8-2	HEATER
009	S3-D10	HEAT RESIST PLATE			
011	S3-D15	MOTOR RACKET			
012	S3-D16	REAR PLATE			
013	S3-D17	SPRING			
014	S3-D18-1	SPRING			
015	S3-P1	AC MOTOR			
015-1	S3-P1-1	CONDENSER			
016	S3-P2	PCB			
017	S3-D19	POWER S.W			
018	3LM-B7	KNOB			

